



POWER SUPPLY			
VOLTS	230VAC	Hz	50
MAX MOTOR LOAD			
WATTS	500	AMPS	2.1
PROTECTIVE FUSE			
F1 - 4	5A		
OPERATING TEMP RANGE			
°C	-40 TO +85		

Instructions

1. Connect a suitable 230v AC mains supply to **"POWER"** terminals
2. Connect all 230v AC tubular type motors to connections **"MOTOR 1 - 4"** as shown
3. Connect either key-switch or push button station to **"MOTOR CENTRAL"** terminals to control all shutters simultaneously **and/or** **"MOTOR MANUAL"** terminals for individual shutter operation

Any unused stop circuits must be bridged between STOP and COM

Optional Accessory Transmitter
 AC129 4Channel Transmitter (Not supplied with unit)
 (Max no 5 transmitters per channel)

To Program

Select channel using **⏪** **⏩** buttons

Ch1 ■■■■
 Ch2 ■■■■
 Ch3 ■■■■
 Ch4 ■■■■
 Group ■■■■

Press Required Channel button on the receiver - **ONCE** only

Press **⏪** button, receiver LED will confirm acceptance

Micro USB to recharge

To Delete Transmitters
 Press and hold channel button on the receiver unit until the channel light flashes quickly, release button and quickly press once more transmitter are now deleted

This drawing is the property of ELLARD LTD, it may not be reproduced without the written authorization of Ellard Limited. All intellectual property rights are expressly reserved

ELLARD
 Roundthorne Industrial Estate
 Ellard House, Floats Road
 Wythenshawe, Manchester
 M23 9WB
 Tel: 0161 945 4561, e-mail: technical@ellard.co.uk

Title
**EASY GROUP
 (4 WAY TUBE MOTOR
 GROUP CONTROLLER)**

Rev/Notes

<u>Date</u>	01/02/2022		
<u>Drawn by</u>	DE	<u>Chk'd by</u>	AP
<u>Drg #</u>	EASY GROUP - General Set Up		